

© Carl

2017/001 V02



PROG-RUN

ATtiny programmer shield


3x

mode

10 μ F/16V



RESET



R1
10k




C2
100nF




C3
100nF




C4
100nF



ATtiny10/11/12/13/15
ATtiny22/25/45/85



ATtiny
24/44/84




ATtiny2313
ATtiny4313

Digital I/O
SCK 13
MISO 12
MOSI 11
RESET 10

Digital I/O
7 6 5 4 3 2 1
R2 270
R3 270
R4 270
uploading

Error!

ISPrunning



In Circuit System
Programmer socket

IO_r
RST
3.3V
5V
Gnd
Gnd
V_{in}

0 1 2 3 4 5
Analog In